

APPENDIX II (U)**REFERENCES****1. Publication Indexes**

The following indexes should be consulted frequently for the latest changes or revisions of references given in this appendix and for new publications relating to the materiel covered in this manual.

Index of Administrative Publications	DA Pam 310-1
Index of Army Motion Pictures, Film Strips, Slides, and Photo-Recordings	DA Pam 108-1
Index of Blank Forms	DA Pam 310-2
Index of Graphic Training Aids and Devices	DA Pam 310-5
Index of Supply Manuals, Ordnance Corps	DA Pam 310-29
Index of Doctrinal, Training, and Organizational Publications (Field Manuals, Reserve Officers Training Corps Manuals, Training Circulars, Army Subject Schedules, Army Training Tests, Firing Tables and Trajectory Charts, Tables of Organization and Equipment, Type Tables of Distribution and Tables of Allowances	DA Pam 310-3
Index of Technical Manuals, Technical Bulletins, Supply Manuals (Types 4, 6, 7, 8 and 9), Supply Bulletins, Lubrication Orders, and Modification Work Orders	DA Pam 310-4

2. Supply Manuals

The following supply manual pertains to this materiel.

Ammunition, Explosives, Bulk Propellants, and Explosive Devices	SM 9-5-1375
---	-------------

3. Forms

The following forms pertain to this materiel.

Equipment, Inspection and Maintenance Worksheet	DA Form 2404
Equipment Maintenance Records, Organizational	DA Form 2408-3
Maintenance Request	DA Form 2407
Materiel Inspection and Receiving Report	DD Form 250
Rejection Memorandum	DA Form 829
Report of Damaged or Improper Shipment	DD Form 6
Request for Issue or Turn-In	DA Form 1546

4. Other Publications

The following explanatory publications contain information pertinent to this materiel and associated equipment.

a. Camouflage.

Camouflage, Basic Principles	FM 6-20
------------------------------------	---------

b. Decontamination.

Decontamination	TM 3-220
Defense Against CBR Attack	FM 21-40

c. Destruction to Prevent Enemy Use.

Demolition Materials	TM 9-1946
Explosives and Demolitions	FM 5-25
Operators Manual: Destruction of NIKE Guided Missile Systems Materiel to Prevent Enemy Use (NIKE-AJAX, NIKE-HERCULES Air Defense Guided Missile Systems)	TM 9-1400-250-10/3

CONFIDENTIAL

CONFIDENTIAL

C8

d. General.

Accident Reporting and Records.....	AR 385-40
Army Safety Program.....	AR 385-10
Authorized Abbreviations and Brevity Codes.....	AR 320-50
Corrosion Control and Treatment.....	TB 9-337
Dictionary of United States Army Terms.....	AR 320-5
First Aid for Soldiers.....	FM 21-11
Military Symbols.....	FM 21-30
Military Terms.....	FM 21-5
Northern Operations.....	FM 31-71
Ordnance Direct Support Service.....	FM 9-3
Ordnance General and Depot Support Service.....	FM 9-4
Ordnance Major Items and Major Combinations, and Pertinent Publications.....	SB 9-1
Organization, Policies, and Responsibilities for Maintenance Operations.....	AR 750-5
Organizational Maintenance NIKE-HERCULES Launching and Handling Equipment (NIKE-HERCULES and Improved NIKE-HERCULES Air Defense Guided Missile Systems).....	LO 9-1400-250-20
Organizational Maintenance NIKE-HERCULES Radar Course-Directing Central (NIKE-HERCULES and Improved NIKE-HERCULES Air Defense Guided Missile Systems).....	LO 9-1430-250-20
Report of Malfunctions and Accidents Involving Ammunition and Explosives During Training and Combat.....	AR 700-1300-8
Techniques of Military Instruction.....	FM 21-6

e. Technical Manuals.

Army Equipment Record Procedures.....	TM 38-750
Operation and Maintenance of Army Materiel in Extremely Cold Weather 0° to -65°.....	TM 9-207
Materials Used for Cleaning, Preserving, Abrading, and Cementing Ordnance Materiel; and Related Materials Including Chemicals.....	TM 9-247
Painting Instructions for Field Use.....	TM 9-213
Preservation, Packaging, and Packing of Military Supplies and Equipment.....	TM 38-230
Preventive Maintenance Services (NIKE-AJAX, NIKE-HERCULES, Improved NIKE-HERCULES Air Defense Guided Missile Systems).....	TM 9-1400-250-12
Use and Care of Hand Tools and Measuring Tools.....	TM 9-243

CONFIDENTIAL

INDEX (U)

	Paragraph	Page
AAR shelter	22.2b	30.2
Acquisition antenna (See Antenna, acquisition)		
Acquisition antenna pedestal (See Pedestal, acquisition antenna)		
Acquisition modulator (See Modulator, acquisition)		
Acquisition radar operator's position and duties (See Director station, trailer mounted)		
Acquisition radar system; technical data	9b	15
Acquisition receiver-transmitter (See Receiver-transmitter, acquisition)		
Air conditioning room	21f	30
AJAX rocket motor hoist beam (See Beam, hoist, rocket motor, AJAX)		
Alternate field wire pair trunk lines (See Communications)		
Altitude plotting board (See Plotting boards)		
Amplifier, klystron	21f, 21.1f	30
Antenna, acquisition	25b	47
Antenna, auxiliary	25f	47
Antenna, coupler group	21b, 21.1c	28, 30
Antenna group	22.2a	30.2
Antenna, HIPAR	22c, 22.1c	30.1, 30.2
Antenna, omni, HIPAR	22b, 22.1b	30.1
Antenna-receiver-transmitter group, LOPAR	25	47
Antenna-receiver-transmitter group, missile track	26c	47
Antenna-receiver-transmitter group, target range	26b	47
Antenna-receiver-transmitter group, target track	26a	47
APS filler and service equipment	56g	75
Assembly and service area:		
Function	14c	20.2
Physical layout	15, 16a	22
Assembly area	53	73
Assembly area HERCULES missile test set (See Test set, assembly area, HERCULES missile)		
Auxiliary acquisition control interconnecting group (See Control interconnecting group, auxiliary acquisition)		
Auxiliary acquisition radar	22.2	30.2
Auxiliary antenna (See Antenna, auxiliary)		
Azimuth indicator (See Indicator, azimuth)		
Azimuth operator's position and duties (See Tracking station, trailer mounted)		
B scope indicator (See Indicator, B scope)		
Battery charging rack MT-1498/G	56i	75
Battery control area:		
Function	14a	20.2
Physical layout	15, 16	22
Battery control console (See Console, battery control)		
Battery control officer's position and duties (See Director station, trailer mounted)		
Beam, hoist, HERCULES missile body	56l	78
Beam, hoist, rear body section	56m	78
Beam, hoist, rocket motor, AJAX	56p	78
Beam, hoist, rocket motor cluster	56k	78
Beam, hoist, rocket motor, missile	56o	78
Beam, hoist, warhead body section	56n	78
Blue equipment status (See Equipment status)		
Bomb scoring equipment, radar	23g	40.1
Cabinet station, intercommunication	42b	60
Capabilities (See specific item)		
Circuits:		
Command detonation	48e	67
Fail-safe control	48e	67
Receiving and decoding	48b	67
Steering control	48d	67
Transmitting	48c	67

CONFIDENTIAL

	Paragraph	Page
Coder set, radar	24a	43
Command detonation circuits (See Circuits)		
Comments, criticisms, corrections	3.1	9
Communications:		
Between guided missile launching set and battery control console	33	63
Emergency communication system, functional description:		
Alternate field wire pair trunk lines	75b(1)	93
Emergency field wire pairs	75b(3)	93
Radio sets	75b(2)	93
Intercom system, functional description	74	92
Telephone system, functional description	73	92
Completed engagement, report of	66	87
Computer group	23f, 23.1e	40, 40.7
Condenser, refrigerant	21.1j	30.1
Console, battery control	23c, 23.1b	30.2, 40.1
Console, launching control	42a	58
Console, missile radar control	24a	46
Console, target radar control	24a	43
Consolidated site (See Radar course directing central)		
Control-indicator, countermeasures	24c(5)	46
Control-indicator, HERCULES launching section	41a	57
Control-indicator, launcher	40	57
Control-indicator, power	21.1j	30.1
Control-indicator, transmitter	21e	28
Control interconnecting group, auxiliary acquisition	23d	39
Control-monitor, HIPAR	21a	30
Control-oscillator group	21.1k	30.1
Control, target ranging radar	24f	47
CONUS B launching section (See Launching sections, NIKE-HERCULES)		
CONUS C launching section (See Launching sections, NIKE-HERCULES)		
CONUS C modified launching section (See Launching sections, NIKE-HERCULES)		
CONUS D modified launching section (See Launching sections, NIKE-HERCULES)		
Countermeasures control-indicator (See Control-indicator, countermeasures)		
Department of the Army (DA MWO's)	2a.1, b	9
Depot maintenance (fifth echelon) (See Maintenance)		
Designation of target (See Target)		
Determination and establishment of equipment status (See Equipment status)		
Director station group	23a	30.2
Director station, trailer mounted:		
Description	23, 23.1	30.2, 40.1
Operator positions:		
Acquisition radar	23a(3)	50.1
Battery control officer	23a(1), 23a.1(1), (4), (5)	50.1, 51
Early warning plotting board	23a(5), 23a.1(6)	51
Fire control	23a(4)	51
Long range surveillance	23a.1(1), (3), (5)	51
Short range surveillance	23a.1(1), (2), (5)	51
Switchboard	23a(6), 23a.1(6)	51
Tactical controller	23a(2)	50.1
Early warning plotting board operator's position and duties (See Director station, trailer mounted)		
Early warning plotting board (See Plotting boards)		
Echelons of maintenance (See Maintenance)		
Elevation indicator (See Indicator, elevation)		
Elevation operator's position and duties (See Tracking station, trailer mounted)		
Emergency communication system (See Communications)		
Emergency field wire pairs (See Communications)		

	Paragraph	Page
Emergency mode (<i>See</i> Targets)		
Emergency operating procedures (<i>See</i> Procedures, emergency operating)		
Equipment, handling	56	75
Equipment status:		
Determination and establishment	59	88
Local designation during blue equipment status	71c	91
Local designation during red equipment status	71d	91
Local setting	71b	90
Surface-to-air low altitude mission	69	90
Surface-to-air mission:		
Blue	68b	88
Red	68c	88
White	68a	87
Surface-to-surface mission:		
Blue	70a	90
Red	70b	90
Fail-safe control circuits (<i>See</i> Circuits)		
Fault locating indicator (<i>See</i> Indicator, fault locating)		
Field maintenance (third and fourth echelons) (<i>See</i> Maintenance)		
Filter, RF harmonic	21.1d	30
Fire control operator's position and duties (<i>See</i> Director station, trailer mounted)		
FLI mode (<i>See</i> Targets)		
Flight simulator group (<i>See</i> Simulator group, flight)		
Forms, records, and reports	3	9
Forward body section (<i>See</i> Missile body)		
Forward body section truck (<i>See</i> Truck, forward body section)		
FUIF identification (<i>See</i> Targets)		
Guidance system, missile:		
Beam rider	6b(2)	10
Command	6b(3)	10
Description	48	67
Homing	6b(1)	10
Guided missile launching set:		
Communications	33	53
Functional description	29	53
Indicators	32	53
Launching control	30	53
Operating power sources	34	53
Physical arrangement	35	53
Safety provisions	31	53
Guided missile M6:		
Functional description; aerodynamic configuration	47	63
Physical description	44	63
Rocket motor cluster	46	63
Handling equipment (<i>See</i> Equipment, handling)		
Handling rack (<i>See</i> Rack, handling)		
Handling ring segment, HERCULES	56g	78
HERCULES handling ring segment (<i>See</i> Handling ring segment, HERCULES)		
HERCULES launching section control-indicator (<i>See</i> Control-indicator, HERCULES launching section)		
HERCULES launching section selector (<i>See</i> Selector, HERCULES launching section)		
HERCULES missile body hoist beam (<i>See</i> Beam, hoist, HERCULES missile body)		
HERCULES missile body truck (<i>See</i> Truck, HERCULES missile body)		
HERCULES monorail launcher (<i>See</i> Launcher, monorail, HERCULES)		
HERCULES section simulator group (<i>See</i> Simulator group, HERCULES section)		
High voltage power supply (<i>See</i> Power supply, high voltage)		
High voltage pulse generator (<i>See</i> Pulse generator, high voltage)		
HIPAR antenna (<i>See</i> Antenna, HIPAR)		
HIPAR antenna radome-support-tripod (<i>See</i> Radome-support-tripod, HIPAR antenna)		

	Paragraph	Page
HIPAR building and equipment (See NIKE-HERCULES ATBM Air Defense Guided Missile System) (See also Improved NIKE-HERCULES Air Defense Guided Missile System)		
HIPAR control-monitor (See Control-monitor, HIPAR)		
HIPAR omni antenna (See Antenna, omni, HIPAR)		
History of development	6	10
Hoisting unit, portable	56j	78
Horizontal plotting board (See Plotting boards)		
Identification of targets (See Targets)		
IFF mode (See Targets)		
Improved NIKE-HERCULES Air Defense Guided Missile System:		
Capabilities	8	13
Function	4, 5	9, 10
Functional description	10	17
HIPAR building and equipment	21	28
Operational areas	14	20.2
Operating conditions	8d	13
Tactical application	7	11
Tactical control	58	83
Indicator, azimuth	24c(2)	44
Indicator, B scope	24c(3)	45
Indicator, elevation	24c(1)	43
Indicator, fault locating	43.1	62
Indicator, precision	23c(4)	39
Indicators (See Guided missile launching set)		
Indicator, target range	24c(4)	45
Induction voltage regulator (See Regulator, voltage, induction)		
Inline configuration (See Radar course directing central)		
Intercommunication cabinet station (See Cabinet station, intercommunication)		
Intercom system (See Communications)		
Klystron amplifier (See Amplifier, klystron)		
Launcher control-indicator (See Control-indicator, launcher)		
Launcher, monorail, HERCULES:		
Description	38	56
Equipment used for testing	55a	99
Launching area:		
Function	14b	20.2
Physical layout	15, 16b, c, d, 36	22, 53
Launching area HERCULES missile test set (See Test set, launching area HERCULES missile)		
Launching control (See Guided missile, launching set)		
Launching control console (See Console, launching control)		
Launching control station, trailer mounted	42	58
Launching-handling rail (See Rail, launching-handling)		
Launching sections, NIKE-HERCULES:		
CONUS B	37c	55
CONUS C	37b	55
CONUS C modified	37c	55
CONUS D modified	37d	55
Liquid cooler	21c, 21.1d	28, 30.1
Local designation during blue equipment status (See Equipment status)		
Local designation during red equipment status (See Equipment status)		
Local setting of equipment status (See Equipment status)		
Long range surveillance operator's position and duties (See Director station, trailer mounted)		
LOPAR antenna-receiver-transmitter group (See Antenna-receiver-transmitter group, LOPAR)		
Main fins and elevons (See Missile body)		

	Paragraph	Page
Maintenance:		
Categories	77	96
Depot (fifth echelon)	80	97
Field (third and fourth echelons):		
Definition	79	96
Test equipment:		
Characteristics	84	99
Description of specific equipment	86	99
General	83	99
Purpose	85	99
General theory of	76	96
Missile support	81	98
Organizational (first and second echelons)	78	96
Technical assistance for echelons:		
Contract field technicians	82b	98
Maintenance technicians	82d	98
Manufacturer's representative	82a	98
Regional maintenance representatives	82c	98
Missile:		
Firing	64	84
Monitoring	65	87
Technical data	9a	16
Missile body:		
Equipment used for testing	86a	99
Forward section	45b	63
Main fins and elevons	45c	63
Rear section	45d	63
Warhead section	45e	63
Missile body or rocket motor cluster transporter adapter (See Transporter, adapter, missile body or rocket motor cluster)		
Missile flat bed trailer M261A1	56e	71
Missile guidance set group	36b	99
Missile guidance system (See Guidance system, missile)		
Missile maintenance support (See Maintenance)		
Missile radar control console (See Console, missile radar control)		
Missile rocket motor hoist beam (See Beam, hoist, rocket motor, missile)		
Missile track antenna-receiver-transmitter group (See Antenna-receiver-transmitter group, missile track)		
Missile tracking operator's position and duties (See Tracking station, trailer mounted)		
Missile tracking radar system; technical data	9c	16
Missile-warhead combinations	63	85
Missions:		
Radar bomb scoring:		
Capabilities	8c.1	13
Functional description	13.1, 14.4	19, 20.3
Surface-to-air:		
Capabilities	3a	13
Functional description	11a, 14.2	17, 20.3
Selection of warhead	63a, 63b	85
Surface-to-air antiaircraft:		
Capabilities	8.1a	14.1
Functional description	14.2a	20.3
Selection of warhead	63b	85
Surface-to-air anti-missile:		
Capabilities	8.1b	14.1
Functional description	14.2a	20.3
Selection of warhead	63b	85

	Paragraph	Page
Missions—Continued		
Surface-to-air low altitude:		
Capabilities	8b	19
Functional description	12	19
Selection of warhead	63a	86
Surface-to-surface:		
Capabilities	8c, 8.1c	13, 14.1
Functional description	13, 14.3	19, 20.3
Selection of warhead	63a, 63b	86
Modulator, acquisition	25e	47
Moving target indicator group	21p, 21.1p	30
NIKE-HERCULES ATBM System:		
Capabilities	8.1	14.1
Function	4, 5	9, 10
HIPAR building and equipment	21.1a	30
Operational areas	14.5	20.3
Operating conditions	8.1d	14.1
Overall functional description	14.1	20.2
Tactical application	7	11
Tactical control	58	83
NIKE-HERCULES launching sections (See Launching sections, NIKE-HERCULES)		
Nomenclature	2d	9
Nonconsolidated site (See Radar course directing central)		
Operating conditions (See Improved NIKE-HERCULES Air Defense Guided Missile System) (See also NIKE-HERCULES ATBM System)		
Operating power sources (See Guided missile launching set)		
Organizational maintenance (first and second echelons) (See Maintenance)		
Pedestal, acquisition antenna	25c	47
PI mode (See Targets)		
Plotting boards:		
Altitude	23c(2), 23.1b(2)	34.1, 40.1
Early warning	23e	40
Horizontal	23e(1), 23.1b(1)	32, 40.1
Portable hoisting unit (See Hoisting unit, portable)		
Power control-indicator (See Control-indicator, power)		
Power distribution unit (See Unit, power distribution)		
Power supply group, radar	24b	43
Power supply, high voltage	21k, 21.1b	28, 30
Power supply truck (See Truck, power supply)		
PPI	23e(3), 23.1b(3)	38, 40.3
Precision indicator (See Indicator, precision)		
Pressurizer, waveguide	21g	28
Procedures, emergency operating	71	90
Propulsion system	50	69
Pulse generator, high voltage	21f, 21.1e	30
Purpose of manual	1	9
Rack, handling	58A	75
Radar antenna support set (See Support set, antenna, radar)		
Radar bomb scoring equipment (See Bomb scoring equipment, radar)		
Radar bomb scoring mission (See Missions)		
Radar coder set (See Coder set, radar)		
Radar course directing central:		
Equipment used for testing	86a	100
Functional description	17, 18	23
Physical arrangement:		
General	19	25
Inline configuration:		
Consolidated site	20a	26
Nonconsolidated site	20b	26
"T" configuration	20.1	26

	Paragraph	Page
Radar power supply group (See Power supply group, radar)		
Radar set group	24d	46
Radar target simulator (See Simulator, radar target)		
Radar test set group (See Test set group, radar)		
Radio sets (See Communications)		
Radome	22.1c	30.1
Radome-support-tripod, HIPAR antenna	22a	30.1
Rail, launching-handling	39	56
Rear body section hoist beam (See Beam, hoist, rear body section)		
Receiver group, EFS	21m, 21.1A	30, 30.01
Receiver-transmitter, acquisition	25d	47
Receiving and decoding circuits (See Circuits)		
Reciprocating compressor, power driven, trailer-mounted	56f	75
Recorder group	23b	30.2
Red equipment status (See Equipment status)		
Refrigerant condenser (See Condenser, refrigerant)		
Regulator, voltage, induction	21g, 21.1m	28, 30.1
Report of completed engagements (See Engagements completed, report of)		
RF harmonic filter (See Filter, RF harmonic)		
Rocket motor cluster (See Guided missile MI - 14A)		
Rocket motor cluster hoist beam (See Beam, hoist, rocket motor cluster)		
Rocket motor cluster truck (See Truck, rocket motor cluster)		
Safety provisions (See Guided missile launching set)		
Scope of manual	2	9
Selection of targets for engagement (See Targets)		
Selector, HERCULES launching section	41	57
Service area	54	73
Short range surveillance operator's position and duties (See Director station, trailer mounted)		
SIF/IPF identification (See Targets)		
Simulator group, flight:		
Description	42	61
Equipment used for testing	36b	99
Simulator group, HERCULES section	41b	58
Simulator, radar target	42d	61
Stabilized local oscillator	21d	28
Steering control circuits (See Circuits)		
Step-up power transformer (See Transformer, power, step-up)		
Support set, antenna, radar	22.1a	30.1
Surface-to-air antiaircraft mission (See Missions)		
Surface-to-air anti-missile mission (See Missions)		
Surface-to-air low altitude mission (See Missions) (See also Equipment status)		
Surface-to-air mission (See Missions) (See also Equipment status)		
Surface-to-surface mission (See Missions) (See also Equipment status)		
Switchboard operator's position and duties (See Director station, trailer mounted)		
"T" configuration (See Radar course directing central)		
T1 trainer	27.1	50.1
Tactical application (See Improved NIKE-HERCULES Air Defense Guided Missile System) (See also NIKE-HERCULES ATBM System)		
Tactical control (See NIKE-HERCULES ATBM System)		
(See also Improved NIKE-HERCULES Air Defense Guided Missile System)		
Tactical controller's position and duties (See Director station, trailer mounted)		
Target radar control console (See Console, target radar control)		
Target range antenna-receiver-transmitter group (See Antenna-receiver-transmitter group, target range)		
Target range indicator (See Indicator, target range)		
Target range operator's position and duties (See Tracking station, trailer mounted)		
Target ranging radar control (See Control, target ranging radar)		
Target ranging radar system; technical data	9d	16

CONFIDENTIAL**C5**

	Paragraph	Page
Targets:		
Designation	62	86
Identification:		
FUIF	61a	83
SIF/IFF interrogation modes:		
Emergency	61b(4)	85
FLI	61b(3)	85
IFF	61b(1)	85
PI	61b(2)	85
Selection for engagement	III	83
Target track antenna-receiver-transmitter group (See Antenna-receiver-transmitter group, target track)		
Target tracking radar system; technical data	9c	15
Technical assistance for echelons of maintenance (See Maintenance)		
Technical data (See specific item)		
Telephone system (See Communications)		
Test equipment for field maintenance (See Maintenance)		
Test set, assembly area, HERCULES missile	57	78
Test set group, radar	27	48
Test set, launching area HERCULES missile	48	61
Tracking station, trailer mounted:		
Description	24	48
Operator positions:		
Azimuth	28b(1)	51
Elevation	28b(2)	51
Missile tracking	28b(5)	52
Target range	28b(3)	52
Tracking supervisor	28b(4)	52
Tracking supervisor's position and duties (See Tracking station, trailer mounted)		
Trailer mounted director station (See Director station, trailer mounted)		
Trailer mounted launching control station (See Launching control station, trailer mounted)		
Trailer mounted power driven reciprocating compressor (See Reciprocating compressor, power driven, trailer mounted)		
Trailer mounted tracking station (See Tracking station, trailer mounted)		
Transformer, power, step-up	21.1a	30.1
Transmitter control-indicator (See Control-indicator, transmitter)		
Transmitting circuits (See Circuits)		
Transporter adapter, missile body or rocket motor cluster	56d	75
Truck, forward body section	56b	75
Truck, HERCULES missile body	56a	75
Truck, power supply	56r	78
Truck, rocket motor cluster	56c	76
Unit, power distribution	21i	28
Warhead body section (See Missile body)		
Warhead body section hoist beam (See Beam, hoist, warhead body section)		
Warhead system	51	69
Waveguide pressurizer (See Pressurizer, waveguide)		
White equipment status (See Equipment status)		

CONFIDENTIAL

CONFIDENTIAL

By Order of *Wilber M. Brucker*, Secretary of the Army:

G. H. DECKER,
General, United States Army,
Chief of Staff.

Official:

R. V. LEE,
Major General, United States Army,
The Adjutant General.

Distribution:

Active Army:

To be distributed in accordance with DA Form 12-7 requirements for TM 9 Series (CLASS) Plus the following Formula:

DCSLOG (1)	1st GM Bde (50)
Tech Stf, DA (1) except	Units org under fol TOE:
CofOrd (3)	(3 copies each)
USARADCOM (2)	9-510 (CONUS Only)
USARADCOM Egn (2)	44-544
MDW (1)	44-545
WSMR (10)	44-546
1st Msl Bn, 61st AAA (12)	44-547
1st Msl Bn 43rd AAA (12)	44-548

NG: Units org under fol TOE: 44-545 (4); 44-546, 44-547 (1).

USAR: None

For explanation of abbreviations used, see AR 320-50.

CONFIDENTIAL

CONFIDENTIAL

CONFIDENTIAL